HermanMiller

Renew[™] Sit-to-Stand Tables



Intuitive Paddle Adjustment Guide

How to adjust the height of the table

You will know the table is working when the paddle turns blue.



Press up on the paddle to raise the table.

Press down on the paddle to lower the table.

How to calibrate the table

The table will need to be calibrated at the time of installation so legs are in sync with each other, or if the legs become out of sync during operation.



Adjust the table to the lowest height.

Release the paddle.

Press the paddle down and hold it for 5–10 seconds.

The table will begin to readjust itself if necessary. Release the button once the table has stopped moving and clicking.

How to save a lower and upper height limit



Raise or lower the table to desired height.

Locate the black button on the underside of the table, behind the paddle.

Press and hold the black button until you hear two quiet clicks (10–15 seconds).


Once you hear two clicks, release the button.

How to clear a lower or upper height limit



of the saved height limits.

Raise or lower the table to one



hear one click (10-15 seconds).





HermanMiller Renew Sit-to-Stand Tables 1 Adjustment Guide