


8. Operating Remote Control



Button	Function
ON/OFF	Switching lighting group 1 ON/OFF
Left arrow	Reducing the brightness
Right arrow	Increasing the brightness
Color wheel	Setting the color temperature

- A. Switching the lights ON/OFF
Press button ON/OFF to switch on all lighting.
Press the button once more to switch off the lighting.

- B. Setting the brightness
The brightness can be set gradually or continuously.

Gradual Setting (100 % - 75 % - 50 % - 25 % - 0 %)

Press the left arrow button to reduce the brightness gradually. Press the right arrow button to increase the brightness gradually.

Continuous Setting

Keep the left arrow button pressed to reduce the brightness continuously. Keep the right arrow button pressed to increase the brightness continuously

OR

Rotate the wheel to adjust brightness up or down.