

# User Guide

## Toggle and Digital Switch— For Use with k.™ bench Height-Adjustable Tables

The k. bench Toggle Switch and Digital Switch are designed for use with k. bench Height-Adjustable Tables only. The intuitive Toggle Switch offers light-touch responsiveness for table height adjustment. The Digital Switch features basic up and down buttons, programmable quick sit and stand buttons, and a digital read-out of table height. This document details switch set up and programming.




### Digital Switch

#### Reset the Table



*Perform reset before first use*

*Perform each time Collision Detection is activated*





- 1 Clear the area around and under the table
- 2 Press and hold  for until table is at minimum height.
- 3 Press and hold  for 5 seconds, or until display indicates flashing.
- 4 Press and hold ; table will move down below Min height to mechanical lower limits (both columns hit hard stops) then table will move back up to Min height. Display will indicate Min height in inches.

#### Program Sit Height

- 1 Move table to preferred seated height.
- 2 Press 
- 3 Press  [S - 1] to store location.




#### Program Stand Height

- 1 Move table to preferred standing height.
- 2 Press 
- 3 Press  [S-2] to store location.




#### Program Upper Limit and/or Lower Limit

Set an upper or lower limit when planning with storage that interferes with table adjustment range.

##### Upper Limit:



- 1 Move table to preferred Upper Limit height.
- 2 Press  [S - ]
- 3 Press  [S -, blinks ]
- 4 Press and hold  for 2 seconds [999] to store location.

##### Lower Limit:

- 1 Move table to preferred Lower Limit height.
- 2 Press  [S - ]
- 3 Press  [S -, blinks ]
- 4 Press and hold  for 2 seconds [000] to store location.

#### Clear Upper Limit and/or Lower Limit:

Clearing Limits is required to change Upper Limit or Lower Limit.

- 1 Press  [S - ]
- 2 Press and hold  for 2 seconds [555] to clear any limits previously set.

#### Operating the Table

The k. bench switch enters stand-by mode after 10 seconds of inactivity. Press any button to activate the system. When active, the digital switch will show the table's current height in inches (or centimeters).

- 1 Press and hold  or  or   button to adjust the height of the table.